

| Document Title: <h1>Installation Sheet, ATMOS 41 all models, Particulate Screen</h1> | | Part # <h1>18596</h1> | |
|---|---|---------------------------------------|---------|
| | | Release Date: <h1>12.2025</h1> | |
| Rev. | Description | Revision By | Date |
| 00 | Original release per Asana task 26161 tied to ECO 25256 | EMR | 12.2025 |
| | | | |
| | | | |

Web File Link:

http://publications.metergroup.com/Instruction%20Sheets/18596_ATMOS41-particulate-screen_Print.pdf

Working File Name:

[SharePoint/Sites/Product Number Library/18500-18599/18596](#)

Dimensions: 3.75 inches x 3.75 inches, cut and trim from 8.5 x 11 cardstock (4 double-sided printed to a page)

Colors: CMYK/Full Color 4/4

Printer Type: Out of house or In-House Printer

Material: Card stock, Bright White, 216 g/m² (folding cardstock)

Image below is for reference only. Not to scale.

PARTICULATE SCREEN INSERT

The particulate screen reduces debris in the ATMOS 41 funnel.

METER
IMPORTANT: Using this screen can interfere with precipitation measurement accuracy, especially in cases of very low rainfall.

The particulate screen can be inserted before or after installation (depending on height/access), and with or without the bird deterrent spikes on the funnel.

1. Remove the particulate screen from packaging and line up the half circle cut out to fit around the outside of the pyrannometer.

NOTE: The edge of the screen are sharp. Use care or wear gloves to avoid any injuries.

2. Gently but firmly press the screen into the funnel.
3. (Re)install the ATMOS 41 as needed following the install video or user manual instructions available at [metergroup.com](#).

PARTICULATE SCREEN INSERT

The particulate screen reduces debris in the ATMOS 41 funnel.

METER
IMPORTANT: Using this screen can interfere with precipitation measurement accuracy, especially in cases of very low rainfall.

The particulate screen can be inserted before or after installation (depending on height/access), and with or without the bird deterrent spikes on the funnel.

1. Remove the particulate screen from packaging and line up the half circle cut out to fit around the outside of the pyrannometer.

NOTE: The edge of the screen are sharp. Use care or wear gloves to avoid any injuries.

2. Gently but firmly press the screen into the funnel.
3. (Re)install the ATMOS 41 as needed following the install video or user manual instructions available at [metergroup.com](#).

4. Check the bubble level and relevel as needed. The Zentra Utility Mobile app will aid proper leveling.

To remove the particulate screen, use a small blunt object such as a screwdriver to gently pry up from the edge of the screen.

Scan the QR code below for more ATMOS 41/41W resources or go to [metergroup.com](#).

METER Group, Inc.
2385 NE Highway Court,
Palmira, WA 99103
T +1 509.332.2750 F +1 509.332.5158
E info@metergroup.com W [metergroup.com](#)
NORTH AMERICA
E support.us@metergroup.com
T +1 509.332.5800
EUROPE
E support.eu@metergroup.com
T +49 99 12 88 52 0

meter.ly/41resources

4. Check the bubble level and relevel as needed. The Zentra Utility Mobile app will aid proper leveling.

To remove the particulate screen, use a small blunt object such as a screwdriver to gently pry up from the edge of the screen.

Scan the QR code below for more ATMOS 41/41W resources or go to [metergroup.com](#).

METER Group, Inc.
2385 NE Highway Court,
Palmira, WA 99103
T +1 509.332.2750 F +1 509.332.5158
E info@metergroup.com W [metergroup.com](#)
NORTH AMERICA
E support.us@metergroup.com
T +1 509.332.5800
EUROPE
E support.eu@metergroup.com
T +49 99 12 88 52 0

meter.ly/41resources