

2.125"

4.375"

6.625"

8.875"

6Z081

51-11-90

6Z081

51-11-90

6Z081

51-11-90

6Z081

51-11-90

3.25"

3.25"

**Instructions
Read First**

1. Replace the flat cap with the nozzle cap and ensure it is well secured.
2. Hold the red cap and shake well.
3. Take a clean kimwipe and wipe up the nozzle as you remove the red cap from the nozzle tip.
4. Drip two or three drops into a waste container. Make sure not to touch the nozzle tip to the container.
5. Fill a sample cup until the bottom of the cup is covered.
6. Recap the standard bottle. Put the lid on the sample cup and label it. Under most conditions, the sample cup containing the standard can be used for up to 4 hours if kept covered and sealed with parafilm when not being read.
7. Make sure the red cap remains on the standard bottle at all times when not in use.
8. There might be some salt crystallization around the cap and nozzle for .760 a_w standard. It can be wiped off with a tissue and disposed of in the trash. Do not rinse the bottle.

Have Questions?

📞 1-509-332-5601

✉ support@aqualab.com

**Instructions
Read First**

1. Replace the flat cap with the nozzle cap and ensure it is well secured.
2. Hold the red cap and shake well.
3. Take a clean kimwipe and wipe up the nozzle as you remove the red cap from the nozzle tip.
4. Drip two or three drops into a waste container. Make sure not to touch the nozzle tip to the container.
5. Fill a sample cup until the bottom of the cup is covered.
6. Recap the standard bottle. Put the lid on the sample cup and label it. Under most conditions, the sample cup containing the standard can be used for up to 4 hours if kept covered and sealed with parafilm when not being read.
7. Make sure the red cap remains on the standard bottle at all times when not in use.
8. There might be some salt crystallization around the cap and nozzle for .760 a_w standard. It can be wiped off with a tissue and disposed of in the trash. Do not rinse the bottle.

Have Questions?

📞 1-509-332-5601

✉ support@aqualab.com

**Instructions
Read First**

1. Replace the flat cap with the nozzle cap and ensure it is well secured.
2. Hold the red cap and shake well.
3. Take a clean kimwipe and wipe up the nozzle as you remove the red cap from the nozzle tip.
4. Drip two or three drops into a waste container. Make sure not to touch the nozzle tip to the container.
5. Fill a sample cup until the bottom of the cup is covered.
6. Recap the standard bottle. Put the lid on the sample cup and label it. Under most conditions, the sample cup containing the standard can be used for up to 4 hours if kept covered and sealed with parafilm when not being read.
7. Make sure the red cap remains on the standard bottle at all times when not in use.
8. There might be some salt crystallization around the cap and nozzle for .760 a_w standard. It can be wiped off with a tissue and disposed of in the trash. Do not rinse the bottle.

Have Questions?

📞 1-509-332-5601

✉ support@aqualab.com

**Instructions
Read First**

1. Replace the flat cap with the nozzle cap and ensure it is well secured.
2. Hold the red cap and shake well.
3. Take a clean kimwipe and wipe up the nozzle as you remove the red cap from the nozzle tip.
4. Drip two or three drops into a waste container. Make sure not to touch the nozzle tip to the container.
5. Fill a sample cup until the bottom of the cup is covered.
6. Recap the standard bottle. Put the lid on the sample cup and label it. Under most conditions, the sample cup containing the standard can be used for up to 4 hours if kept covered and sealed with parafilm when not being read.
7. Make sure the red cap remains on the standard bottle at all times when not in use.
8. There might be some salt crystallization around the cap and nozzle for .760 a_w standard. It can be wiped off with a tissue and disposed of in the trash. Do not rinse the bottle.

Have Questions?

📞 1-509-332-5601

✉ support@aqualab.com