

Document Title:  <b>Description File LIT, IS, AROYA Scales</b>		Part #  <b>18441</b>	
		Release Date: <b>1.15.2021</b>	
<b>Rev.</b>	<b>Description</b>	<b>Revision By</b>	<b>Date</b>
0	Initial release of file for DFM Sheet 08302 <a href="https://app.asana.com/0/24162392409147/1198488269135933">https://app.asana.com/0/24162392409147/1198488269135933</a>	LAJ	1.15.2021

**Production Filename:**

[http://publications.metergroup.com/Instruction%20Sheets/18441\\_AROYA\\_Scales\\_IS\\_Print.pdf](http://publications.metergroup.com/Instruction%20Sheets/18441_AROYA_Scales_IS_Print.pdf)

**Working File Path:**

/Volumes/GoogleDrive/Shared drives/Product Number Library/18400-18499/18441


**Dimensions:** Printed on 8.5"x11"; cut in half to finalize size of 8.5" x 5.5"

**Publication Method:** Web or Printed in house

**Colors:** Full Color

**Materials:** White Card Stock 80#

**Image below is for reference only. Not to scale.**



## AROYA SCALES INSTRUCTION SHEET

18441 IS  
1.15.2021

### METER

#### Preparation

The AROYA H510 Portable Scale and H511 Bench Scale connect to [app.aroya.io](http://app.aroya.io) on a Microsoft® Windows® personal computer (PC) or Apple® Mac® computer through the Google Chrome™ browser. The PC or Mac must be capable of using Bluetooth® Low Energy (BLE).

Confirm that the scale arrives intact.

Read the full Ohaus® Range 3000 (for H510 portable scale) or Ohaus Defender 3000 (for H511 bench scale) manual at website [ohaus.com](http://ohaus.com).



#### Installation

Set up and prepare the scale by following the manufacturer's instructions.

NOTE: If an AROYA H510 Scale Cut-off is to be used for the AROYA H510 Portable Scale to allow for hanging plants, please place the scale on the cart. Secure the back (and side with H510 portable scale) into the front of the scale before proceeding.

Visit [app.aroya.io](http://app.aroya.io) on a PC or Mac through the Google Chrome browser.

Follow the AROYA app instructions for connecting to the scale and viewing weight measurements.

**METER Group, Inc. USA**  
 2365 NE Hopkin Court, Pullman, WA 99163  
 T+1.509.332.5844 F+1.509.332.5158  
 Esupport@aroya.com Wmetergroup.com