

Document Title:		Part #	
Description file Manual, 2-Inch Sample Ring Adapter KSAT & HYPROP		18502	
		Release Date: 12.2021	
Rev	Description	Revision By	Date
00	Posted to repository per Put KSAT 2-inch adapter manual on library.metergroup.com so Kersten can add to website. Thank you! This adapter is used with the KSAT and Hyprop	LAJ	12.2021
01	Updated to match present METER tech literature; updated to be accurate to changes made in the design of the 2-inch adapter. DCO 19734 https://app.asana.com/0/308057532565579/1204562090372409/f	EMR	12.2023

Production Location: http://publications.metergroup.com/Manuals/UMS/18502_KSAT-HYPROP_2-inch_Adapter_Manual.pdf

Working Location:

<https://csicloud.sharepoint.com/:f:/r/sites/Product%20Number%20Library/Shared%20Documents/18500-18599/18502?csf=1&web=1>

Dimensions: 12.5-in wide x 8-in tall (folded, 6.25-in W x 8-in H)

Colors: CMYK/Full color 4/4

Printer: Web only

Image below is for reference only. Not to scale.



METER

2-INCH ADAPTER MOUNTING AND APPLICATION INSTRUCTION SHEET

Use this instruction sheet for:

- Measuring 100 ML soil samples with KSAT and additional HYPROP
- Measuring 100 ML soil samples with HYPROP

KSAT and HYPROP are designed to be used with a 250 ML soil sample ring. The 2-inch adapter enables 100 ML soil samples to be measured. This instruction sheet covers soil saturation for KSAT (page 2) and HYPROP (page 13) measurements, and mounting the 2-inch adapter for 100 ML soil samples for KSAT (page 7) and HYPROP (page 11).

ACCESSORIES

Below are the accessories used and described in this guide. Learn more at metergroup.com.

