

Document Title: <b>Description, Instruction sheet, ATMOS41W/ATMOS Gen 2 Wind speed collar</b>		Part # <b>18575</b>	
		Release Date: <b>5.17.24</b>	
<b>Rev</b>	<b>Description</b>	<b>Revision By</b>	<b>Date</b>
00	Original Release, <a href="#">ID: 24775</a>	KB	02.14.25

**Print File Path:** [https://publications.metergroup.com/Instruction%20Sheets/18575\\_ATMOS\\_Wind-speed-collar\\_IS\\_Print.pdf](https://publications.metergroup.com/Instruction%20Sheets/18575_ATMOS_Wind-speed-collar_IS_Print.pdf)

**Working File Path:** [SharePoint/Product number library/18500-18599/18575/](#)

**Dimensions:** 5.375 in wide x 5 in tall (calendar folded, title facing out), 5.375 in wide x 10 in tall (not folded)

**Colors:** CMYK/Full color 4/4

**Printer Type:** In-house printing or at approved vendor, or ELECTRONIC ONLY  
**If electronic only, material category not needed**

**Material:** Card stock, Bright White, 216 g/m2 (folding cardstock)  
**Color copy digital refers to the file used for printing out manual**

**Special Notes:** Image below is for reference only (not to scale); File in Product Library

**METER** **ATMOS 41W/ATMOS 41 GEN 2**  
**Wind Speed Collar**


This document instructs how to re-zero the windspeed for the ATMOS 41W and ATMOS 41 GEN 2 for the wind speed collar installation.

Zentra Utility Mobile must be installed and accessible on a mobile device in order to properly re-zero the wind speed. Ensure Zentra Utility Mobile version 1.18 or later is downloaded. To download Zentra Utility Mobile scan the QR code or go to <https://meter.ly/4u7d03E>.



**RE-ZEROING FOR THE ATMOS 41W**


1. Disconnect the ATMOS 41W rain funnel.



2. Press the TEST button. The green and red lights will blink, indicating the module is ready to connect with ZENTRA Utility Mobile.



3. Open the Zentra Utility Mobile app. There may be a prompt to conduct a firmware update. Update the firmware by following the directions on screen before continuing.



Cut/trim at 5 3/8  
(5.375) inches

Fold

Cut/trim 1 inch of bottom  
for end dimensions 5.375 x  
10 inches before folding.