



We Measure the World

2365 NE Hopkins Court  
Pullman, Washington 99163  
phone 509-332-2756  
website [www.decagon.com](http://www.decagon.com)

## Decagon Devices, Inc. Product Market Information Sheet

**Product:** Decagon 5TM

**Description:** Soil sensor which continuously measures both temperature and soil moisture. Soil moisture is measured using frequency domain technology while temperature is measured using a thermistor in thermal contact with length of sensor. Sensor requires 3-16 VDC and has a digital output. A stereo plug on the sensor allows the sensor to plug into Decagon's Em50 Data logger.

The 5TM contains patented technology (patented by Decagon Devices, Inc.) for monitoring soil moisture using frequency domain technology. The patent covers the ability of the sensor to accurately monitor soil moisture in a variety of soil types and soil salinities. The sensor is, by design, accurate and rugged at a price that allows researchers to easily characterize spatial variability.

**Distributors of Product:** Decagon is the sole distributor of the 5TM in the USA to universities and other research institutions.

**Competitors with similar products:** None known.

---