



We Measure the World

2365 NE Hopkins Court
Pullman, Washington 99163
phone 509-332-2756
website www.decagon.com

Decagon Devices, Inc. Product Market Information Sheet

Product: Decagon Em50

Description: Data logger containing 5 ports to monitor and record data from Decagon sensors. Data logger is powered by 5 AA batteries. The data logger can monitor both digital and analog sensors from Decagon's sensor line including, but not limited to, the 5TE, EC-TM, EC-5, and 10HS. ECHO Utility software or DataTrac software are used to download and view data from the data loggers. Data logger enclosure has IP55 and NEMA 3 ratings, which classifies the logger enclosure as highly weather, wind, and dust resistant. Data logger reads all sensors every minute and reports minute average data at the measurement interval specified by the user using the accompanying software. The data logger can store 36,000 scans of each sensor plugged into the data logger.

Distributors of Product: Decagon Devices, Inc. is the sole distributor of the Em50 in the USA to universities and other research institutions.

Competitors with similar products: None known with the capabilities of the Em50 logger.