

Decagon Devices, Inc. Product Market Information Sheet

Product: Decagon Em5b

Description: Data logger containing 5 ports to monitor and record data from Decagon sensors. Data logger is powered by 4 AAA batteries. The data logger can monitor analog sensors from Decagon's sensor line including, but not limited to, the EC-5, and 10HS. ECHO Utility software is used to download and view data from the data loggers. The data logger enclosure has impact-resistant IP52, NEMA 3 ratings.

Data logger reads all sensors every minute and reports minute average data at the measurement interval specified by the user using the accompanying software. The data logger can store 3,4000 scans of each sensor plugged into the data logger.

Distributors of Product: Decagon Devices, Inc. is the sole distributor of the Em5b in the USA to universities and other research institutions.

Competitors with similar products: None known with the capabilities of the Em5b logger.